

The steps to adjust 55510-CGV-02 (speedometer) to fit for proper tires.

1) check the battery to be correctly assembled



2) pull out the plug of wireharness ready



3) turn the key on



4) push two bottoms of speedometer at the same time and follow step 5)



5) to connect the speedometer to the plug of wireharness then release the bottoms.



6) then release the bottoms and you may see the 0000 on the display as picture.



7) to fill the correct values (note 1) to the speedometer by two bottoms pushing



The right bottom is number digits (0,1,2,3,4,5,6,7,8,9) in one push.



The left bottom is “ left moving forward” bottom. Move the digit you need to the left side forward.



After getting digits you need, to push two bottoms at the same time again to finish the set-up. The speedometer will work normally.

Note 1

The table of the digits

Diameter of rear tire(inch)	SPROCKET,DRIVEN (T)			
	32T	34T	36T	38T
18(inch)	393	418	443	467
19	372	396	419	442
20	353	376	398	420
21	337	358	379	400
22	321	342	362	381